

## Efficiency

**Unit:** Heat & Thermodynamics

**NGSS Standards:** HS-PS2-6

**MA Curriculum Frameworks (2006):** N/A

**AP Physics 2 Learning Objectives:** N/A

**Skills:**

- calculate the efficiency of a thermodynamics process

**Language Objectives:**

- Understand and correctly use the term efficiency in a scientific context.
- Set up and solve word problems relating to thermal efficiency.

**Notes:**

efficiency ( $\eta$ ): the ratio of the energy consumed by a device or process to the energy output by the device or process.

Assume that a heat engine starts with a certain temperature, which means a certain internal energy ( $U$ ). The engine takes heat from a heat source at the incoming temperature  $T_{in}$ , does work ( $W$ ), and exhausts heat at the higher temperature  $T_{out}$ . Assuming the internal energy of the machine itself stays constant, this means  $\Delta U = 0$ . Therefore, from the First law:

$$\Delta U = 0 = \Delta Q - \Delta W$$

$$0 = Q_{in} - Q_{out} - \Delta W$$

$$\Delta W = Q_{in} - Q_{out}$$

Use this space for summary and/or additional notes.

A 100% efficient heat engine would turn all of the heat into work, and would exhaust no heat ( $Q_{out} = 0$ , which would mean  $\Delta W = Q_{in}$ ). Of course, real engines cannot do this, so we define efficiency,  $e$ , as the ratio of work out to heat in, *i.e.*:

$$e = \frac{\Delta W}{\Delta Q_{in}} = \frac{\Delta Q_{in} - \Delta Q_{out}}{\Delta Q_{in}} = \frac{\Delta Q_{in}}{\Delta Q_{in}} - \frac{\Delta Q_{out}}{\Delta Q_{in}} = 1 - \frac{\Delta Q_{out}}{\Delta Q_{in}}$$

Because the engine is doing work,  $\Delta W > 0$ , which means  $0 \leq e \leq 1$ . Furthermore, a consequence of the Second law is that some energy is always lost to the surroundings (entropy), which means  $Q_{out} > 0$  and therefore  $0 \leq e < 1$ .

### Sample Problem

Q: 80. J of heat is injected into a heat engine, causing it to do work. The engine then exhausts 20. J of heat into a cool reservoir. What is the efficiency of the engine?

A:  $Q_{in} = 80 \text{ J}$  and  $Q_{out} = 20 \text{ J}$ . Therefore:

$$e = 1 - \frac{\Delta Q_{out}}{\Delta Q_{in}} = 1 - \frac{20}{80} = 1 - 0.25 = 0.75$$

Because efficiency is usually expressed as a percentage, we would say that the engine is 75% efficient.

Use this space for summary and/or additional notes.

The following table gives energy conversion efficiencies for common devices and processes. In all of these cases, the “lost” energy is converted to heat that is given off to the surroundings.

**Energy Conversion Efficiency**

<b>Device/Process</b>	<b>Typical Efficiency</b>
gas generator	up to 40%
coal/gas fired power plant	45%
combined cycle power plant	60%
hydroelectric power plant	up to 90%
wind turbine	up to 59%
solar cell	6–40%; usually 15%
hydrogen fuel cell	up to 85%
internal combustion engine	25%
electric motor, small (10–200 W)	50–90%
electric motor, large (> 200 W)	70–99%
photosynthesis in plants	up to 6%
human muscle	14–27%
refrigerator	20%
refrigerator, energy-saving	40–50%
light bulb, incandescent	0.7–5%
light bulb, fluorescent	8–16%
light bulb, LED	4–15%
electric heater	100%
firearm	30%

You may notice that an electric heater is 100% efficient, because all of its energy is converted to heat. However, this does not mean that electric heat is necessarily the best choice for your home, because the power plant that generated the electricity was probably only 45% efficient.

Use this space for summary and/or additional notes.

### Heating Efficiency

Heating efficiency is calculated in a similar way. The difference is that the energy produced by the heater is  $Q_{out}$ , which means:

$$\eta = \frac{Q_{out}}{Q_{in}} = \frac{\text{usable heat out}}{\text{total energy in}}$$

“Usable heat out” means heat that is not lost to the environment. For example, if the boiler or furnace in your house is 70% efficient, that means 70% of the energy from the gas or oil that it burned was used to heat the steam, hot water or hot air that was used to heat your house. The other 30% of the energy heated the air in the boiler or furnace, and that heat was lost to the surroundings when the hot air went up the chimney.

Older boilers and furnaces (pre-1990s) were typically 70% efficient. Newer boilers and furnaces are around 80% efficient, and high-efficiency boilers and furnaces that use heat exchangers to collect the heat from the exhaust air before it goes up the chimney can be 90–97% efficient.

Use this space for summary and/or additional notes.

## Efficiency of Heat Pumps

Carnot's theorem states that the maximum possible efficiency of a heat pump is related to the ratio of the temperature of the heat transfer fluid (liquid or gas) when it enters the heat pump to the temperature when it exits:

$$\eta \leq 1 - \frac{T_{in}}{T_{out}}$$

Note that the Carnot equation is really the same as the efficiency equation in the previous section. Recall that for heating or cooling a substance:

$$Q = mC\Delta T = mC(T_{out} - T_{in})$$

The refrigerant is the same substance, which means  $mC$  is the same for the input as for the output, and it drops out of the equation.

It is a little counter-intuitive that a higher temperature difference means the heat pump is more efficient, but you should think about the fact that the job of the heat pump is to move heat between one side and the other. In other words, the more heat you pump into the refrigerant, the higher its temperature will be when it leaves the system, and therefore the more efficiently the pump is moving heat. Conversely, if  $T_{out} = T_{in}$ , then the heat pump is not moving any heat and the efficiency is zero.

### Sample Problem

Q: Refrigerant enters a heat pump at 20.°C (293 K) and exits at 300.°C (573 K).  
What is the Carnot efficiency of this heat pump?

A: Carnot's equation states that:

$$\eta = 1 - \frac{T_{in}}{T_{out}} = 1 - \frac{293}{573}$$
$$\eta = 1 - 0.51 = 0.49$$

*i.e.*, this heat pump is 49% efficient.

Use this space for summary and/or additional notes.